



FISCHER SKI BOOTS SIZING

MONDOPOINT	US MEN'S	US WOMEN'S	EU	UK
22	4	5	35	3
22.5	4.5	5.5	36	3.5
23	5	6	36.5	4
23.5	5.5	6.5	37	4.5
24	6	7	38	5
24.5	6.5	7.5	38.5	5.5
25	7	8	39	6
25.5	7.5	8.5	40	6.5
26	8	9	40.5	7
26.5	8.5	9.5	41	7.5
27	9	10	42	8
27.5	9.5	10.5	42.5	8.5
28	10	11	43	9
28.5	10.5	11.5	44	9.5
29	11	12	44.5	10
29.5	11.5	*	45	10.5
30	12	*	45.5	11
30.5	12.5	*	46	11.5
31	13	*	47	12
31.5	13.5	*	47.5	12.5
32	14	*	48	13
32.5	14.5	*	48.5	13.5
33	15	*	49	14
33.5	15.5	*	50	14.5
34	16	*	51	15